

Series 801LED-FCP

Logic5™ Surface 4" Flat Canopy Plate 8.4W LED PAR16

Installation Instructions (Retrofit)(Flat Canopy Plate)

CLARTÉ™

LIGHTING

CAUTION!

READ AND FOLLOW ALL SAFETY AND INSTALLATION INSTRUCTIONS CAREFULLY.
TURN OFF ELECTRICAL POWER BEFORE STARTING INSTALLATION.

IMPORTANT SAFEGUARDS:

Suitable to Install on “*Dimming Circuits*”.

NOTE--Work should be performed by qualified personnel.

All wiring must be in accordance with all applicable NEC Standards



SAVE THESE INSTRUCTIONS

WARNING! Before starting installation, disconnect power by turning off the circuit breaker or by removing the appropriate fuse at the fuse box. Turning the power off by using the light switch is not sufficient to prevent electric shock. Do Not install any luminaire assembly closer than 6" from any curtain or similar combustible materials. Risk of fire most dwellings built before 1985 have supply wire rated 60° C. Work must be done by a state licensed electrician "For use with ceiling mounted track only" For supply connections use wire rated for at least 90° C

1. Remove old fixture (if applicable).
Expose the supply wiring from the outlet box.
2. CLARTÉ's Flat Canopy Plate fits into a 4-0 J-Box with Plaster Mud Flange with screw holes 2 3/4" apart
3. Connect the Fixture BLACK wire to Power line BLACK wire.
4. Connect the Fixture White wire to Power line White wire.
5. Connect the Fixture Ground wire to Power line Ground wire.
6. Use U.L. Listed wire connectors suitable for the size, type, and number of conductors. All wiring must be in accordance with all applicable NEC Standards
7. No loose strands or loose connections should be present.
8. Place Flat Canopy Plate against Plaster Mud Flange and secure screws through canopy plate.
9. Adjust the angle of reflector to the desired position. Restore electricity and check the operation of your new **CLARTÉ** light fixture.

