

SMR1-601-FCP-FX-PAR8

CLARTÉ™ LIGHTING

Installation Instructions (Retrofit/Fixed)(Flat Canopy Plate)

CAUTION!

READ AND FOLLOW ALL SAFETY AND INSTALLATION INSTRUCTIONS CAREFULLY. TURN OFF ELECTRICAL POWER BEFORE STARTING INSTALLATION.

WARNING - Before starting installation, disconnect power by turning off the circuit breaker or by removing the appropriate fuse at the fuse box. Do not install any luminaire assembly closer than 6" from any curtain or similar combustible materials. Risk of fire or electric shock. Luminaire wiring and electrical parts may be damaged when drilling for installation of LED retrofit kit. Check for enclosed wiring and components. Risk of fire or electric shock. LED Retrofit Kit installation requires knowledge of luminaires electrical systems. If not qualified, do not attempt installation. Contact a qualified electrician. Risk of fire or electric shock. Install this kit only in luminaires that have the construction features and dimensions shown in the photographs and/or drawings and where the input rating of the retrofit kit does not exceed the input rating of the luminaire. To prevent wiring damage or abrasion, do not expose wiring to edges of sheet metal or other sharp objects. Do not make or alter any open holes in an enclosure of wiring or electrical components during kit installation. **Consult a qualified electrician before installing. Work should be performed by qualified personnel.**

Suitable to install on **"Dimming Circuits"**.

SAVE THESE INSTRUCTIONS

1. Remove old fixture (if applicable).
Expose the supply wiring from the outlet box.
2. CLARTÉ's Flat Canopy Plate fits into a 4-0 J-Box with Plaster Mud Flange with screw holes 2 3/4" apart
3. Connect the Fixture BLACK wire to Power line BLACK wire.
4. Connect the Fixture White wire to Power line White wire.
5. Connect the Fixture Ground wire to Power line Ground wire.
6. Use U.L. Listed wire connectors suitable for the size, type, and number of conductors. All wiring must be in accordance with all applicable NEC Standards
7. No loose strands or loose connections should be present.
8. Place Flat Canopy Plate against Plaster Mud Flange and secure screws through canopy plate.
9. Adjust the angle of reflector to the desired position. Restore electricity and check the operation of your new **CLARTÉ** light fixture.

