




# RR6-615-NC-PAR30

6" Recessed Downlight 36W

Installation Instructions (New Construction)

# CLARTÉ™ LIGHTING



6. Pull Transformer Pig Tail through opening



7. Connect Transformer pigtail with LED.



8. Insert LED fixture into opening and press firmly into the clips until securely in place.



9. Tighten screws to secure LED fixture to ceiling opening.



10. Restore electrical Power and check the operation of your new CLARTÉ light fixture.